

CARE, MAINTENANCE AND CLEANING - LAMINATE

The flooring surface is designed for durability and high wear resistance, ensuring long-lasting protection. It comes pre-finished and requires no additional treatment. However, proper maintenance and cleaning are essential, and specific guidelines should be followed to preserve its quality.

- *To prevent issues with board dimensions and static loads, maintain ideal conditions of 50%-70% relative humidity and approximately 20°C.*
- *Use a humidifier if necessary.*
- *Avoid varnishing, sanding, or polishing the laminate flooring. Products containing wax, soap, or polish may leave unwanted residues.*
- *Do not attach the laminate flooring to the subfloor or any structural elements using glue, nails, fixed door stops, or other fasteners.*
- *Protect furniture and chair legs with felt or plastic pads, regularly inspecting and cleaning them to prevent damage.*
- *Use chairs with soft wheels to avoid floor damage. If unavailable, place a polycarbonate mat under the chair to prevent direct contact with the flooring.*
- *Place doormats at exterior entrances to minimize the entry of dirt, dust, gravel, and moisture from outside.*
- *Clean the floor using a broom, cleaning pad, or a vacuum with a parquet brush. A well-wrung mop can also be used.*
- *Avoid abrasive cleaning tools such as wire wool, scouring pads, or cleaning machines.*
- *Use non-abrasive, pH-neutral detergents, preferably those with an eco-label.*
- *For grooved surfaces, avoid sharp, pointed, or abrasive tools. Use a vacuum with a parquet brush. If needed, gently wipe with a slightly damp cloth.*
- *To remove stubborn stains from the surface (never in joints or grooves), use a mild solution of diluted acetone or household alcohol, then rinse with water.*
- *Take extra care in areas with pets, as urine can damage the laminate flooring. Clean up accidents immediately to prevent harm.*
- *Wipe up any spilled water immediately to ensure no moisture remains on the surface.*